

Model: WS Concrete Box 200X160 Family: WALL-SMART

DWG NO. 10-04-181-SPC

PRODUCT SPEC.

21/June/2015

DATE



## **Make Your Wall Smart**

## Wall-Smart concrete/block installation box:

Wall should be plastered up to the front frame segments (item #1).

Model No.: 10-01-181

- Front frame segments (item #1) should be removed after the wall was plastered (to be replaced with the adapter).
- For low voltage use only.
- Before installation, read Wall-smart installation instruction No. 10-01-00103-INS

