

Model: WS NC FOR IPAD PRO12.9 5&6 AIR13M2 WITH GRILLS +ETHERNET

DWG NO. 002-4-371E-WG-SPC

Family:

PRODUCT SPEC

**WALL-SMART** 

DEPTH CALIBRATION SCREWS

DATE 21/MAY/2024

POE TO USB **CONVERTER WITH** 

**ETHERNET** 

#### **Make Your Wall Smart**

## "WS NC FOR IPAD PRO12.9 5&6 AIR13M2 WITH GRILLS +ETHERNET" - Product description:

Model No.: 002-1-371E-WG

The "WS NC FOR IPAD PRO12.9 5&6 AIR13M2 WITH GRILLS +ETHERNET" is wall adapter for in-wall flush installation of an iPad Pro 12.9 5<sup>th</sup> & 6<sup>th</sup> Gen. & iPad Air 13" M2. The "WS NC FOR IPAD PRO12.9 5&6 AIR13M2 WITH GRILLS +ETHERNET" firmly mounts the iPad while allowing easy insertion, removal and operation.

#### Key features and benefits:

- iPad is recessed 1.4mm [0.055"] into the wall surface.
- Wall mount may be mounted in any orientation.
- Includes depth calibration mechanism.
- Includes 10/100 ethernet connectivity.
- The wall mount contains audio grills.
- Paintable with the wall paint in any color and texture.
- Allows easy insertion and removal of the iPad.
- The adapter is supplied unpainted (To be painted after installation as part of the wall).
- Designed to be installed in ½" drywall. Installation of the Wall-Smart adapter is straight-forward. Installation process is similar to drywall construction procedures.
- For installation in concrete/block wall use "CONCRETE BOX 406X306" P/N 100-1-683 (sold separately) according installation instruction 10-04-00103-INS in http://www.wall-smart.com/fag
- Designed for the use with Apple iPad Pro 12.9 5<sup>th</sup> & 6<sup>th</sup> Gen. & iPad Air 13" M2 (iPad is not included).
- Adapter kit contains:
  - 1. Wall adapter (X1)

### **Key properties:**

- Dimensions: (W/H/D): 405mm (15.94")/ 304.8mm (12.0")/ 38.8mm(1.53")
- Power Supply: Wall mount includes POE to USB converter with Ethernet. The installer should connect the wall mount to an IEEE 802.3at POE+ power source via CAT5/6 cable and RJ45 connector. (Please verify the power source can supply up to 25.5W)
- See Page 3 For ethernet configuration.
- In case Ethernet connectivity is not necessary, consider using SKU# 002-1-371-WG with charging capability only.

Weight: 1.7Kg, 3.74lbs. Material: Moisture resistant MDF (compliant with TSCA Title VI) To be installed in ½" drywall (for installation in 5/8" drywall use 1/8" shim pack P/N 10-01-067 (sold separately)). iPad\* is a trademark of Apple Inc., registered in the U.S. and other countries. PUSH HERE TO REMOVE DRYWALL THICKNES BETWEEN DRYWAL [10.27]260.8 12.00] [14.21] 361 BETWEEN DRYWALL [15.94] [1.53]

by Wall-Smart Ltd.

UNI ESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS INFORMATION CONTAINED HEREIN IS PROPRIETARY AND MAY NOT BE USED REPRODUCED OR COPIED WITHOUT WRITTEN CONSENT OF WALL-SMART.



Model: WS NC FOR IPAD PRO12.9 5&6 AIR13M2 WITH GRILLS +ETHERNET

Model No.: 002-1-371E-WG

Family: WALL-SMART


DWG NO. 002-4-371E-WG-SPC




REVISION B


DATE 21/MAY/2024







If required, it is possible to gradually unscrew 4 screws, remove the platform and connect the POE cable after the wall mount is installed.











Model: WS NC FOR IPAD PRO12.9 5&6 AIR13M2 WITH GRILLS +ETHERNET

Family: WALL-SMART

DWG NO. 002-4-371E-WG-SPC



DATE 21/MAY/2024



# **POE to USB converter with Ethernet - Product Specifications**

USB Connector: Type C

• Data Rate: 10/100

• Input Voltage Range: 44-56 volts (IEEE 802.3at compliant)

Model No.: 002-1-371E-WG

Max Power Outpot: 25 watts

Operating Humidity: 5% to 90%

• Operating Temperature Range: -10 – 60c

Output Voltage: 5V,2.6A; 9V,1.78A; 12V,1.34A; 15V,1.37A; 20V,1.15A

Power Input: 25.5 watts

iPad operation system version must be iOS 12.2 or later.

# **Connection steps:**

1. Plug the RJ-45 connector into an IEEE 802.3at PoE (POE+) with a data source.

2. Ensure the device you're connecting to is on and logged in.


**3.** Plug the USB-C connector into the mount.

The converter will automatically set up the network connection with your device and begin charging.

# Configuring the IP:

1. Navigate to Settings and go to "Ethernet".

- **2.** After selecting you'll see all the options for PoE Texas LAN, and your IPV4 IP address information. If it shows "Automatic", that means you're getting a dynamically assigned IP address.
- **3.** If you'd like to reconfigure the IP address, DNS, and HTTP Proxy settings, you can do that here. The most used option will be fixing your IP address by selecting the "Automatic" button.



Phone: (201) 205-2056 / info@wall-smart.com